

## INSTRUCTION SHEET

### CVT-207, CVT-215, CVT-407, CVT-411, CVT-415


(2112120207, 2112120215, 2112120407, 2112120411, 2112120415)



#### SEP Two pole distribution block, 125A / 4,5kA

CVT-207  
2112120207

CVT-215  
2112120215






#### SEP Four pole distribution block, 125A / 4,5kA

CVT-407  
2112120407

CVT-411  
2112120411

CVT-415  
2112120415



				CVT-207 2112120207	CVT-215 2112120215	CVT-407 2112120407	CVT411 2112120411	CVT415 2112120415
2 - 3 Nm	10mm <sup>2</sup> - 35mm <sup>2</sup>	10mm <sup>2</sup> - 25mm <sup>2</sup>	9mm	1x	2x	1x	2x	2x
2 - 3 Nm	10mm <sup>2</sup> - 25mm <sup>2</sup>	6mm <sup>2</sup> - 16mm <sup>2</sup>	7,5mm	1x	2x	1x	2x	2x
2 - 3 Nm	2,5mm <sup>2</sup> - 6mm <sup>2</sup>	1,5mm <sup>2</sup> - 6mm <sup>2</sup>	5,5mm	5x	11x	5x	7x	11x

#### Note:

Unused openings should be tighten to a torque of 0,5 - 1 Nm

#### WARNING:

All products shall be installed and used as indicated by SEP Europe in the instruction sheets and training materials. Products must never be used for a purpose other than which they were designed for or in a manner that exceeds the specified ratings. Installations must be carried out in accordance with the applicable national rules for electrical installations.

SEP Europe® is owned by Schotman Elektro BV®. All other trademarks are the property of their respective owners. Schotman Elektro BV reserves the right to change specifications without prior notice.